

Lug Nut Torque Specifications

Must use a torque wrench for accurate results.

Re-torque lug nuts at 10 miles, 25 miles, and 50 miles, and then periodically after that.

| Stud Size | Lug Nut Type | Torque Specifications | Wheel Size & Type | Wheel Material |
|-----------|--------------------------------|-----------------------|--------------------------|----------------|
| 1/2" | Coned | 90-120 ft.-lb. | 15" & 16" | Steel |
| 5/8" | Coned w/ Wheel Clamp Ring | 190-210 ft.-lb. | 17.5" single or 16" dual | Steel |
| 5/8" | Flanged Nuts (rotating flange) | 190-210 ft.-lb. | 17.5" single or 16" dual | Steel |
| 1/2" | Coned | 90-100 ft.-lb. | 15" & 16" | Aluminum |

Tighten lug nuts in a crisscross pattern as shown below for equal torque distribution.

